BP8 Tech Sheet - for Aftermarket use only

Customer:	Balboa Water Group - Aftermarket Division
Part Number:	G3381 825 Incoloy 3.0kW
Genuine Balboa Box Over	lay
CE System Model For 3.0kW	/: BP21-BP8-RCA3.0K
Software Version ID:	M100_226 V65.0
Software Version:	65.0
File Name:	BP6013_65.0_BP8.hex
Configuration Signature:	A721F573
Eng. Project Number:	5747
Control Panels:	
spaTouch™3	Any version (version 3.2 or later required for Clim8zone [™] heat pump support)
spaTouch™2	Any version (version 2.19 or later required for CHROMAZON∃™ support; version 2.36 or later required for Clim8zone™ heat pump support)
Icon spaTouch™	Any version (version 3.36 or later required for bba™2 fully integrated functionality)
Menued spaTouch™	Any version (version 2.8 or later required for bba™2 integrated functionality)
TP900*	Version 3.1 and later (Version 3.13 or later required for bba™)
TP800	Version 3.1 and later (Version 3.13 or later required for bba™; version 4.11 or later required for bba™2 integrated functionality)
TP700/TP740	Any version
TP600	Version 2.7 and later (Version 2.12 or later required for bba™/bba™2 On/Off control via menu)
TP500	Any version only usable in those Setups that have at most one other piece of equipment (Pump 2 or Blower) in addition to Pump 1
TP400T CE*	Version 2.7 and later (TP400T US should <u>not</u> be used) (Version 2.12 or later required for bba™/bba™2 On/Off control via menu)
TP400W CE*	Version 2.7 and later (TP400W US should <u>not</u> be used) (Version 2.12 or later required for bba™/bba™2 On/Off control via menu)
TP200T*	Any version
TP200W*	Any version

* The TP900 and TP400/TP200 series panels are not supported in all Setups. See the Panel Configuration pages for these panels for details.



System Revision History

Part #	EPN	Date	Originator	Changes Made
G3381	5747	01-22-20	BWG	Generic BP8 system for aftermarket use, combining BP6013G3 with equipment Setups from BP6013G1.

bba[™]2 / bba[™]3 (Balboa Bluetooth Amp) connection is documented separately.

bba[™]2 / bba[™]3 is integrated into graphic display panels (including TP800, TP900, and spaTouch[™]). With TP600/500/400/200, use the "BT" entry on the menu to toggle bba[™]2 / bba[™]3 power On/Off.



Basic Functions Setup 1-18

Power Requirements:

Single Service [3 wires (line, neutral, ground)] 230VAC, 50/60Hz*, 1b, 16A/32A, (Circuit Breaker rating = 20A/40A max.)

Dual Service N/A

3-Service [5 wires (line 1, line 2, line 3, neutral, ground)] 230VAC line-to-neutral**, 50/60Hz*, 3b, 16A, (Circuit Breaker rating = 20A max each phase line.)

HiPot Testing Note:

Disconnect slip terminal with green wires from J6 prior to performing HiPot test. Failure to disconnect may cause a false failure of the test. Reconnect terminal to J6 after successful completion of HiPot test.

* BP systems automatically detect 50Hz vs 60Hz. However, power frequency (50Hz vs 60Hz) is just one of many differences between North American (UL) and CE power, and it is because of these other differences that different BP systems must be used for UL vs CE territories. Also, there are a few countries that use CE power but 60 Hz (such as South Korea) which need CE systems, and a few countries that use UL power but 50 Hz which need UL systems.

** 3-phase service measured line-to-line will read about 400V, but BP systems do not use it line-to-line.

IMPORTANT - Service must include a neutral wire, with a line to neutral voltage of 230VAC.

Notes regarding DIP switch A5 in 1x32A service for Setups 1 - 9:

By default, A5 is configured to be ON in 1x32A service in Setups 1-9, because when running 3 pumps of 12A max each, only 2 of them can be on high-speed at a time.

DIP switch A5 has no effect in Setups 3, 6, and 9 which don't have 3 pumps.

If the 3 pumps are 9A each and <u>no blower</u> is used, then switch A5 can definintely be turned OFF. Between 9A and 10.5A, it depends on whether a circ pump is being used and whether A/V is being used whether DIP switch A5 needs to be ON or can be turned OFF.

If the 3 pumps are 8A each <u>plus a blower</u> is used, then switch A5 can definintely be turned OFF. Between 8A and 9A, it depends on whether a circ pump is being used and whether A/V is being used whether DIP switch A5 needs to be ON or can be turned OFF.

Ie, you have to add up the amperages of all the 230V equipment (including the circ pump if any, the ozone if any, and A/V if any) and make sure it is no more than 32A if you want to turn DIP switch A5 OFF.

Notes regarding DIP switch A5 in 1x16A & 1x32A service for Setups 10 - 18:

By default, A5 is configured to be ON in 1x16A service in Setups 10-18, because when running 1 pump of 12A max, a second pump or blower cannot run at the same time in a 1x16A service. A5 can be turned OFF in 1x32A service in Setups 10-18.

Manufactured under one or more of these patents. U.S. Patents: 5332944, 5361215, 5550753, 5559720, 5,883,459, 6253227, 6282370, 6590188, 6976052, 6965815, 7030343, 7,417,834 b2, Canadian Patent: 2342614, Australian patent: 2373248 other patents both foreign and domestic applied for and pending.



G3381_97_A 03-27-23

Basic Functions Setup 1-18

System Ouputs:

Pump 1	230VAC	2-Speed 12A max 15-minute timer (30-minute timer for P1 Low in non-circ setups of 1-Speed in Setups in Setups 4 - 6, 11, 13 & 15 This is the heater pump in Setups 7 - 9 & 16 - 18. Must deliver 20 GPM through heater								
Pump 2	230VAC		12A max ups 1 - 11 &	15-minute timer 16						
Pump 3	230VAC	•	12A max ups 1, 2, 4, 5	15-minute timer , 7 & 8						
Blower	230VAC	•		15-minute timer , 7, 9, 12, 13 & 17						
Circ Pump	230VAC		2A max heater pump i r 20 GPM thro	Programmable Filtration Cycles + Polling in Setups 1 - 6 & 10 - 15. ough heater						
Ozone	230VAC		.5A max	Slaved to Circ Pump in Circ Setups 1 - 6 & 10 - 15. Independent in Non-Circ Setups 7 - 9 & 16 - 18.						
Spa Light	10VAC	0n/0ff	2A* max	240-minute timer.						
AV + C8Z**	230VAC	Hot	2A+8A max	Always on						
Heater	3.0kW @ 24	OVAC max								


* 2A max limit is shared by On/Off Spa Light <u>and</u> CHROMAZON∃™.

** Optional splitter PN 22934 can be used to connect two things, such as BBA3 and Clim8zone™(C8Z), to J33.



Hardware Setup

Wiring Diagram





Hardware Setup

Settings

SINGLE	SERVICE 230V 1p / 1x	32A & 1x16A	, THREE-SE	ERVICE 230V	3þ / 3x16/	٩					FOR	SETUPS 10	D-18:
LOCATIO							MAX AMPS		CONNECTIONS,		SWITCHBANK S1 OFF		SWITCHBANK S1 ON
J9	NETZSTROMVERSORG						12A		ORS SIZED ON THE	230V 1b			
	ALIMENTATION POM	PE 1 A 2/1	VITESSES 2	/1-SPD PUMP	1		12A		°C AMPACITY BUT	1x32A	ILJI HODE OIT	A1	TEST MODE ON
J14	1-SPD PUMP 2								UM OF 90°C.	INJER	DON'T ADD 1 HS PUMP W/HTR	A2	ADD 1 HS PUMP WITH HEAT
	NETZSTROMVERSORG	UNG 1-GESCH	WPUMPE 2				12A				DON'T ADD 2 HS PUMPS W/HTR		ADD 2 HS PUMPS WITH HEAT
	ALIMENTATION POM	PE 2 A 1 VI	TESSE						CONDUCTORS ONLY.		DON'T ADD 4 HS PUMPS W/HTR		ADD 4 HS PUMPS WITH HEAT
J15	10V BELEUCHTUNG	ECLAIRAGE	BAIN HYDRO	SPA LIGHT			2A* (@10V)	EMPLOYER UN			SPECIAL AMPERAGE RULE A	▲ A5	SPECIAL AMPERAGE RULE B
J21	KREISLAUF PUMPE	POMPE DE C	IRCULATION	CIRC PUMP			2A	DES CONDUCT	EURS DE CUIVRE.		STORE SETTINGS*	▲ A6	MEMORY RESET*
J32	OZONGENERATOR G	ENERATOROZO	NE OZONE G	ENERATOR			0.5A				1 MIN HTR COOLDOWN (ELEC)	▲ A7	5 MIN HTR COOLDOWN (GAS)
J33	AV + CLIM8ZONE™	(C8Z)					2A + 8A	TOROUE RANG	F FOR		NOT ASSIGNED	🛋 A8	NOT ASSIGNED
J44	HEATER						3.0kW		AL BLOCK (TB1):		NOT ASSIGNED	◀ A9	NOT ASSIGNED
* 24 11	MIT IS SHARED BY J15 S	PA LIGHT AN		13 m				27-30 IN. L			NOT ASSIGNED	🗲 A10	NOT ASSIGNED
				-				(31.1-34.5	kg cm)		*SWITCH # 6 SHOULD BE SET TO OFF	UPON FINAL INS	STALLATION.
SETUP #	CIRC PUMP	PUMP 1	PUMP 2	PUMP 3	BLOWER	TEMP SCA	LE			I	SWITCHBANK S1 OFF		SWITCHBANK S1 ON
1	FILTERS + POLLING	2-SPEED	1-SPEED	1-SPEED	1-SPEED	°C	CENU			230V 1þ	TEST MODE OFF	🔺 A1	TEST MODE ON
2	FILTERS + POLLING	2-SPEED	1-SPEED	1-SPEED	NONE	°C				1x16A	DON'T ADD 1 HS PUMP W/HTR	 A2 	ADD 1 HS PUMP WITH HEAT
3	FILTERS + POLLING	2-SPEED	1-SPEED	NONE	1-SPEED	°C				V	DON'T ADD 2 HS PUMPS W/HTR	 A3 	ADD 2 HS PUMPS WITH HEAT
4	FILTERS + POLLING	1-SPEED	1-SPEED	1-SPEED	1-SPEED	°C	- VALB	シ			DON'T ADD 4 HS PUMPS W/HTR	 A4 	ADD 4 HS PUMPS WITH HEAT
5	FILTERS + POLLING	1-SPEED	1-SPEED	1-SPEED	NONE	°C					SPECIAL AMPERAGE RULE A	A5 🕨	SPECIAL AMPERAGE RULE B
6	FILTERS + POLLING	1-SPEED	1-SPEED	NONE	1-SPEED	°C					STORE SETTINGS*	A6	MEMORY RESET*
7	NONE	2-SPEED	1-SPEED	1-SPEED	1-SPEED	°C	-	<u> </u>	DV 3b 3x16A		1 MIN HTR COOLDOWN (ELEC)	A 7	5 MIN HTR COOLDOWN (GAS)
8	NONE	2-SPEED	1-SPEED	1-SPEED	NONE	°C	-1	20	of op onion	I	NOT ASSIGNED	A 8	NOT ASSIGNED
9	NONE	2-SPEED	1-SPEED	NONE	1-SPEED	°C	-1i —		60	I	NOT ASSIGNED	▲ A9	NOT ASSIGNED
10	FILTERS + POLLING	2-SPEED	1-SPEED	NONE	NONE	°C	OFF				NOT ASSIGNED	A10	NOT ASSIGNED
10	FILTERS + POLLING	1-SPEED	1-SPEED	NONE	NONE	0°C	╡¦ ∣◀	A2	4 4 6 6				
12	FILTERS + POLLING	2-SPEED	NONE	NONE	1-SPEED	0°C	┤¦ ◀	A3	L		*SWITCH # 6 SHOULD BE SET TO OFF	UPON FINAL INS	STALLATION.
13	FILTERS + POLLING	1-SPEED	NONE	NONE	1-SPEED	0°C	┤! ◄	A5	TB1				
14	FILTERS + POLLING	2-SPEED	NONE	NONE	NONE	°C		.3 BRN	4 ()		FOR SETUPS 1 - 9, 230V	<u>1þ 1x32A</u>	ONLY (AS MANUFACTURED):
15	FILTERS + POLLING	1-SPEED	NONE	NONE	NONE	°C	1!	1 BRN		153 J12 158 J36	SWITCHBANK S1 OFF		SWITCHBANK S1 ON
16	NONE	2-SPEED	1-SPEED	NONE	NONE	°C		BLU		3	TEST MODE OFF	A 1	TEST MODE ON
17	NONE	2-SPEED	NONE	NONE	1-SPEED	°C		2 BRN			DON'T ADD 1 HS PUMP W/HTR	A2	ADD 1 HS PUMP WITH HEAT
18	NONE	2-SPEED	NONE	NONE	NONE	°C			3	J62 J88	DON'T ADD 2 HS PUMPS W/HTR	4	ADD 2 HS PUMPS WITH HEAT
				TNST	EAD OF			GRN			DON'T ADD 4 HS PUMPS W/HTR		ADD 4 HS PUMPS WITH HEAT
					TUP #1.				REMOVE JUMPE J51-J58	ER WIRES	SPECIAL AMPERAGE RULE A	A5 ►	
\mathbf{H}	ALB((THIS SYS			li –		J52-J36	- I	STORE SETTINGS*	A6	MEMORY RESET*
	@	<i></i>		CONFIGU							1 MIN HTR COOLDOWN (ELEC)	A7	5 MIN HTR COOLDOWN (GAS)
wð	ter grü	υp									NOT ASSIGNED	A8	NOT ASSIGNED
				J			_				NOT ASSIGNED	A9	NOT ASSIGNED
RDQ	- PN G3	2221									NOT ASSIGNED	A10	NOT ASSIGNED
-		JOOT											
01-31-2	3										*SWITCH # 6 SHOULD BE SET TO OFF	UPUN FINAL INS	STALLATION. PART B
													17411 6



Setup Reference Table

Setup #	Circ Pump	Pump 1	Pump 2	Pump 3	Blower	Temp Scale
1	Programmable Filtration + Polling	2-Speed	1-Speed	1-Speed	1-Speed	°C
2	Programmable Filtration + Polling	2-Speed	1-Speed	1-Speed	None	°C
3	Programmable Filtration + Polling	2-Speed	1-Speed	None	1-Speed	°C
4	Programmable Filtration + Polling	1-Speed	1-Speed	1-Speed	1-Speed	°C
5	Programmable Filtration + Polling	1-Speed	1-Speed	1-Speed	None	°C
6	Programmable Filtration + Polling	1-Speed	1-Speed	None	1-Speed	°C
7	None	2-Speed	1-Speed	1-Speed	1-Speed	°C
8	None	2-Speed	1-Speed	1-Speed	None	°C
9	None	2-Speed	1-Speed	None	1-Speed	°C
10	Programmable Filtration + Polling	2-Speed	1-Speed	None	None	°C
11	Programmable Filtration + Polling	1-Speed	1-Speed	None	None	°C
12	Programmable Filtration + Polling	2-Speed	None	None	1-Speed	°C
13	Programmable Filtration + Polling	1-Speed	None	None	1-Speed	°C
14	Programmable Filtration + Polling	2-Speed	None	None	None	°C
15	Programmable Filtration + Polling	1-Speed	None	None	None	°C
16	None	2-Speed	1-Speed	None	None	°C
17	None	2-Speed	None	None	1-Speed	°C
18	None	2-Speed	None	None	None	°C


System (and any replacement board) is shipped in Setup 1



Changing Software Setups with spaTouch™ Icon-Driven Panels

Test Menu Access (S1, Switch 1 ON) Service Technician ONLY. DANGER! HIGH VOLTAGE WILL BE ACCESSIBLE! SERVICE TECHNICIAN ONLY! While the system is running, move DIP Switch 1 (on S1 on the Main circuit board) to ON. The system will enter Test Mode. Moving DIP Switch 1 to OFF will exit Test Mode. 10 **To Change Software Setups:**

While in Test Mode, press the indicated icons to move from screen to screen.





Once on the Setup Selection screen, press the Up or Down icon to select the desired Setup Number, then press the Check Mark icon to confirm and to have the spa restart.

After the system restarts, you may see a message that "The settings have been reset"; this is normal after changing Setups with DIP Switch 6 in the OFF position. Press "Clear" to dismiss this message.




ON 🕨

S1


ON

S1

The example screens shown here are from the spaTouch 1 Icon-Driven Panel, but the screens on the spaTouch 2 Panel are similar. The main difference is that the spaTouch 2 display is wider.



Changing Software Setups with TP800 / TP900 / spaTouch™ Menued Panel





Changing Software Setups with TP600 / TP500 / TP400

Test Menu Access (S1, Switch 1 ON) Service Technician ONLY.

DANGER! HIGH VOLTAGE WILL BE ACCESSIBLE! SERVICE TECHNICIAN ONLY!

While the system is running, move DIP Switch 1 (on S1 on the Main circuit board) to ON. The system will enter Test Mode. Moving DIP Switch 1 to OFF will exit Test Mode.

Software Setups

Under the TEST Menu, the Setup screen will allow changing the Setup from 1 to any number established by the Manufacturer. Changing the Setup may require wiring changes as well.

You will have 1 minute to complete the setup change after you manually exit Priming Mode. (Once familiar with the process, the Setup change should take less than 15 seconds.)



When the panel displays RUN PMPS PURG AIR, press any Temperature button ONCE to exit Priming Mode. You should see "---T" where the T indicates the system is in Test Mode.



Continued on Next Page.

Manufactured under one or more of these patents. U.S. Patents: 5332944, 5361215, 5550753, 5559720, 5,883,459, 6253227, 6282370, 6590188, 6976052, 6965815, 7030343, 7,417,834 b2, Canadian Patent: 2342614, Australian patent: 2373248 other patents both foreign and domestic applied for and pending.



As soon as Switch #1 is placed in the ON position, the temperature will show "T" after it instead of F or C, indicating the System is in Test Mode

Changing Software Setups with TP600 / TP500 / TP400 Continued

Again, You will have 1 minute to complete the setup change after you manually exit Priming Mode.


NOTE: WHerever the below says Warm or Temp folowed by Light, on the TP500 press Menu instead of Warm or Temp followed by light. And whenever the chart below says Light, on the TP500 press Menu insead of Light.

Immediately after exiting Priming Mode, press this sequence of buttons: Warm*, Light, Warm, Warm, Warm. Continue to press Warm until the diplay shows the Setup Number (S-01, S-02, etc.) you want to switch to. When the correct setup number is showing, press Light once, and the system will reset, using the newly-selected Setup from that point on.

Move DIP Switch 1 to the OFF position to take the spa out of Test Mode. °F or °C will replace °T.

Using a permanent marker, write the Setup number on the Setup label mounted inside the system lid (right). This is very important to any service person in the future who may need to replace a circuit board or system and needs to change the Setup on a replacement part while in the field.

NOTE: Changing the Setup may require wiring changes as well - refer to the wiring diagram or wiring diagram addendum.



Manufactured under one or more of these patents. U.S. Patents: 5332944, 5361215, 5550753, 5559720, 5,883,459, 6253227, 6282370, 6590188, 6976052, 6965815, 7030343, 7,417,834 b2, Canadian Patent: 2342614, Australian patent: 2373248 other patents both foreign and domestic applied for and pending. © Copyright 2014 Balboa Water Group.



THIS SYSTEM IS

CONFIGURED AS

Equipment Expansion

Expansion Features Control Connection

Relay 1 (J101) Relay 7/8 (J107)

Default Undefined See below

Fuse None

30A

1-speed Pump 3 + 1-speed Blower (using splitter +fused adapter)


Manufactured under one or more of these patents. U.S. Patents: 5332944, 5361215, 5550753, 5559720, 5,883,459, 6253227, 6282370, 6590188, 6976052, 6965815, 7030343, 7,417,834 b2, Canadian Patent: 2342614, Australian patent: 2373248 other patents both foreign and domestic applied for and pending.



Template 56377 10-05-12

DIP Switch Functions

Fixed-fuction DIP Switches



A2, A3, and A4 work in combination to determine the number of high-speed devices and blowers that can run before the heat is disabled. i.e. A2 and A3 in the ON position and A4 in the OFF position will allow the heater to operate with up to 3 high-speed pumps (or two HS Pumps and Blower) running at the same time. Heat is disabled when the fourth high-speed pump or blower is turned on.

Note: A2/A3/A4 all off = No heat with any high-speed pump or blower.

Assignable DIP Switches

A7 In "ON" position, enables a 5-minute cooldown for some gas heaters (Cooling Time B). In "OFF" position, enables a 1-minute cooldown for electric heaters (Cooling Time A).

Undesignated switches are not assigned a function.

Manufactured under one or more of these patents. U.S. Patents: 5332944, 5361215, 5550753, 5559720, 5,883,459, 6253227, 6282370, 6590188, 6976052, 6965815, 7030343, 7,417,834 b2, Canadian Patent: 2342614, Australian patent: 2373248 other patents both foreign and domestic applied for and pending.



ON 🕨

S1

Jumper Definitions

J109	Not present on BP6013 board.	
J91	Not present on BP6013 board.	
J30	Do Not Use	
J31	Jumper on 1 pin with 2.0kW or smaller heater Jumper on 2 pins with a 3.0kW or higher heater	J31 ⊱
J29	Heater Disable Switch Connection. If J29 is shorted by any means, the heater will not run until J29 is no longer shorted. If J29 is shorted during power-up "J29" will appear on the panel. The message can be dismissed with a button press, and is the only control panel notification of J29 being shorted. No message is displayed if J29 is shorted after power-up, but the heater will not run until J29 is no longer shorted.	J29 💍
	J29 expects a switch closure (not a voltage) as the command signal. In some areas, a local power company may offer discounts based on voluntary "power shedding" devices that may be installed	d in conjunction with the spa.
J25, J26, J27	Not present on BP6013 board.	
 J24	Jumper on center two pins (230V) when heater is running at 240V.	230V

Two Jumpers installed; one on left 2 pins and one on right 2 pins (115V) when heater is running at 120V.



Warning!

Setting DIP switches or jumpers incorrectly may cause abnormal system behavior and/or damage to system components. Refer to Switchbank illustration on Wiring Configuration page for correct settings for this system. Contact Balboa if you require additional configuration pages added to this tech sheet.



Replacement Parts

PCBA:

Main PCBA: Expander PCBA: G1381 59097

HEATER(s):

Plug + Click Heater Kit:58107R163.0kW825 IncTemp Sensor Kit:53605

CABLES:

25681 (fused adapter for Blower) 25859 (splitter)

FUSES:

Part Number	Amperage*	Location
30136	30A	F6, F8, F1 (Expander)
26307	2A	F4
24825	0.125A	F3
26904	10A	F2, F7
26976	3.15A	F5

* The amperages shown above are only intended for identifying fuses on our boards. They are not complete descriptions of those fuses. Please use the part numbers at the left to order fuses directly from Balboa.



General Features		
Feature	Default	
Pump 1 in Filter Cycle (Circ Only)	No	
Pump 1 Low Timer	30 Minutes	Applies in non-circ Setups (configurations) only
General Pump Timer	15 Minutes	Applies to all pumps, except Pump 1 low in Non-Circ Setups
Blower Timer	15 Minutes	
Mister Timer	15 Minutes	
Light Timer	240 Minutes	
Circ (when enabled)	Programmable + Polling	
Cleanup Cycle	30 Minutes	
Cleanup as Preference setting	Yes	
Ozone	With Heater Pump*	
Ozone Suppression	OFF	
Pump Purge	60 Seconds	
Blower Purge	30 Seconds	
Mister Purge	5 Seconds	
Purge Type	Serial - Pumps at lowest s	speed

* The heater Pump can be either a Circ Pump or Pump 1 Low.



Temperature Features

Feature	Default
Temperature Display	°C

All temperatures must be specified in °F. The system converts °F to °C dynamically. If Celsius is required for default settings, choose a desired °C value that (after rounding) corresponds to a Fahrenheit value.

			•	· · ·	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22
°F	39	41	43	45	46	48	50	52	54	55	57	59	61	63	64	66	68	70	72
°C	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	<u>39</u>	40	
°F	73	75	77	79	81	82	84	86	88	90	91	93	95	97	99	100	102	104	
Hi-Range Min. Set Temp 80°F																			
Hi-Range Max. Set Temp 104°F							F												
Hi-Ra	nge [Defaul	t Tem	p*				100°	F										
Lo-Ra	inge I	Min.S	et Tei	mp				50°F											
Lo-Ra	inge l	Max. S	Set Te	mp				99°F											
Lo-Ra	inge [Defaul	t Tem.	ıp*				70°F											
Freez	e Thre	esholo	ł					44°F											
Freezo	е Тур	е						Rotat	ing -	Pump	s at L	owest	Spee	d					
Temp	Lock	Туре						Temp	+ Set	tings									

*May be changed by end-user (if enabled)



.

. .

Time Features

Feature	Default
Time Format*	24 Hour
Filter 1 Start Hour*	20:00 (8:00 PM)
Filter 1 Duration*	2 Hours
Filter Cycle 2 Default*	OFF
Filter 2 Start Hour*	08:00 (8:00 AM)
Filter 2 Duration*	15 Minutes
Light Cycle	Disabled
Light Cycle Default*	OFF
Light Cycle Start Hour*	21:00 (9:00 PM)
Light Cycle Duration*	15 Minutes
Cooling Time A	1 Minute
Cooling Time B	5 Minutes

*May be changed by end-user (if enabled)



Reminder Features

Feature	Default
Reminders Shown*	Yes
Check pH	OFF
Check Sanitizer	OFF
Clean Filter	30 Days
Test GFCI	65 Days
Drain Water	100 Days
Change Cartridge	OFF
Clean Cover	OFF
Treat Wood	OFF
Change Filter	365 Days

*May be changed by end-user (if enabled)

Manufactured under one or more of these patents. U.S. Patents: 5332944, 5361215, 5550753, 5559720, 5,883,459, 6253227, 6282370, 6590188, 6976052, 6965815, 7030343, 7,417,834 b2, Canadian Patent: 2342614, Australian patent: 2373248 other patents both foreign and domestic applied for and pending.



Template 56377 10-05-12

Special Features	
Feature	Default
Special Amperage Rule A	No Limitation
Special Amperage Rule B	2 High Speed Pump Maximum, in Setups 1 - 9 1 High Speed Pump Maximum, and also Blower turns off with 1 High Speed Pump, in Setups 10 - 18
Drain Mode	Disabled
Demo Mode	Disabled
Automatic GFCI Test Ozone Slaved to Heater Pump	Disabled Yes in circ setups No in non-circ setups
Dual Voltage Heater	Always Input Voltage
Safety Suction	Disabled



TP900 Panel Configuration


Button Layout Table

Feature #	Setups 1 & 4	Setups 2 & 5	Setups 3 & 6	Setup 7	Setup 8	Setup 9	TP900 is not supported in Setups 10 - 18.
A1	N/A	N/A	N/A	N/A	N/A	N/A	
A2	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1	
A3	Jets 2	Jets 2	Jets 2	Jets 2	Jets 2	Jets 2	
A4	Jets 3	Jets 3	Blower	Jets 3	Jets 3	Blower	
A5	Blower	Light 1	Light 1	Blower	Light 1	Light 1	
A6	Light 1	Invert	Invert	Light 1	Invert	Invert	
A7	Invert	(Circ Icon)	(Circ Icon)	Invert	Undefined	Undefined	
A8	(Circ Icon)	Undefined	Undefined	Undefined	Undefined	Undefined	
A9	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	
A10	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	
A11	N/A	N/A	N/A	N/A	N/A	N/A	
A12	N/A	N/A	N/A	N/A	N/A	N/A	
A13	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1	
A14	Jets 2	Jets 2	Jets 2	Jets 2	Jets 2	Jets 2	
A15	Jets 3	Jets 3	Blower	Jets 3	Jets 3	Blower	
A16	Light 1	Light 1	Light 1	Light 1	Light 1	Light 1	

A Circ Icon will appear when a Circ Pump is configured.



TP900 Panel Configuration





TP800 Panel Configuration


Button Layout Table

Feature #	Setups 1 & 4	Setups 2 & 5	Setups 3 & 6	Setup 7	Setup 8	Setup 9	Setups 10 & 11	Setups 12 & 13	Setups 14 & 15	Setup 16	Setup 17	Setup 18
A1	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
A2	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1
A3	Jets 2	Jets 2	Jets 2	Jets 2	Jets 2	Jets 2	Jets 2	Blower	Light 1	Jets 2	Blower	Light 1
A4	Jets 3	Jets 3	Blower	Jets 3	Jets 3	Blower	Light 1	Light 1	Invert	Light 1	Light 1	Invert
A5	Blower	Light 1	Light 1	Blower	Light 1	Light 1	Invert	Invert	(Circ Icon)	Invert	Invert	Undefined
A6	Light 1	Invert	Invert	Light 1	Invert	Invert	(Circ Icon)	(Circ Icon)	Undefined	Undefined	Undefined	Undefined
A7	Invert	(Circ Icon)	(Circ Icon)	Invert	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined
A8	(Circ Icon)	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined
A9	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined
A10	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined
A11	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
A12	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
A13	Jets 1	Undefined	Undefined	Jets 1	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined
A14	Jets 2	Undefined	Undefined	Jets 2	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined
A15	Blower	Undefined	Undefined	Blower	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined
A16	Light 1	Undefined	Undefined	Light 1	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined
B1	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1
B2	Jets 2	Jets 2	Jets 2	Jets 2	Jets 2	Jets 2	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined
B3	Jets 3	Jets 3	Blower	Jets 3	Jets 3	Blower	Jets 2	Blower	Undefined	Jets 2	Blower	Undefined
B4	Light 1	Light 1	Light 1	Light 1	Light 1	Light 1	Light 1	Light 1	Light 1	Light 1	Light 1	Light 1




TP800 Panel Configuration

Spa Screen



Note: Button B2 is ALWAYS unused on TP800 when used with this sytsem. A custom overlay will be required.

Shortcuts Screen



Note: Buttons 11 and 12 are not used in this configuration.

Button 1 is fixed.



TP600 Panel Configuration

Button Layout Table

Button #	Setups 1, 4 & 7	Setups 2, 5 & 8	Setups 3, 6 & 9	Setups 10, 11 & 16	Setups 12, 13 & 17	Setups 14, 15 & 18
1	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1
2	Jets 2	Jets 2	Jets 2	Jets 2	Blower	Undefined
3	Jets 3	Jets 3	Blower	Invert	Invert	Invert
4	Temperature	Up	Up	Up	Up	Up
5	Light 1	Light 1	Light 1	Light 1	Light 1	Light 1
6	Blower	Down	Down	Down	Down	Down
LED 1	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1
LED 2	Jets 2	Jets 2	Jets 2	Jets 2	Blower	Undefined
LED 3	Light 1	Light 1	Light 1	Light 1	Light 1	Light 1
LED 4	Heat On	Heat On	Heat On	Heat On	Heat On	Heat On






TP600 Panel Configuration

Setups 2, 3, 5, 6, 8 & 9 can use an overlay such as 12762:

Setups 1, 4 & 7 require a different overlay, such as 13579:



Setups 10 - 18 can use an overlay such as 12101:






TP400/TP200 Panel Configuration

Button #	Setups 10, 11 & 16	Setups 12, 13 & 17	Setups 14, 15 & 18					
1	Temperature	Temperature	Temperature					
2	Jets 1	Jets 1	Jets 1					
3	Light 1	Light 1	Light 1					
4	Jets 2	Blower	Undefined					
LED 1	Heater ON	Heater ON	Heater ON					
LED 2	Jets 1 ON	Jets 1 ON	Jets 1 ON					
LED 3	Light ON	Light ON	Light ON					
LED 4	Jets 2 ON	Blower ON	Undefined					

Button Layout Table for TP400T/TP200T

TP400T/TP200T is not supported in Setups 1 - 9.



TP400T CE

50260-XX includes overlay PN 12511

TP200T

57281-XX with no overlay 57282-XX includes overlay PN 17325

Button Layout Table for TP400W/TP200W

Button Eugout lubic					
Button #	Setups 14, 15 & 18				
1	Up				
2	Down				
3	Light 1				
4	Jets 1				
LED 1	Heater ON				
LED 2	Undefined				
LED 3	Light ON				
LED 4	Jets 1 ON				

TP200W

other equipment.

TP400W CE 50259-XX includes overlay PN 12510

57290-XX with no overlay

Use the TP400W/TP200W for setups that

only have one pump (No Blower or Pump 2), unless using only Aux buttons for the

2510 57283-XX includes overlay PN 17374

Manufactured under one or more of these patents. U.S. Patents: 5332944, 5361215, 5550753, 5559720, 5,883,459, 6253227, 6282370, 6590188, 6976052, 6965815, 7030343, 7,417,834 b2, Canadian Patent: 2342614, Australian patent: 2373248 other patents both foreign and domestic applied for and pending.



Template 56377 10-05-12

Auxiliary Panel Features on Bank 1* Feature Default

Aux Button A1	Jets 1
Aux Button A2	Jets 2
Aux Button A3	Jets 3 in Setups 2, 5 & 8 Blower in other Setups
Aux Button A4	Light

*Bank 1 consists of J5 on the Main Circuit Board. Aux Connection Splitter PN 25257 may be required.

Buttons that are assigned to equipment that is not defined in a Setup will not do anything in that Setup.



Auxiliary Panel Features


AX10 Panels on Bank 1*

 A1, AX10A1
 No 0/L
 52803

 A2, AX10A2
 No 0/L
 52804

 A3, AX10A3
 No 0/L
 52805


 A4, AX10A4
 No 0/L
 52806



Call Customer Service for additional information about Auxiliary Panels.

*Bank 1 consists of J5 on the Main Circuit Board. Aux Connection Splitter PN 25257 may be required.





AX20 Auxiliary Panel plugged into Bank 1 will operate A1 + A2, A3 or A4.

AX40

AX40

No 0/L 52799

AX40 Auxiliary Panel plugged into Bank 1 will operate A1 + A2, A3 and A4.

Manufactured under one or more of these patents. U.S. Patents: 5332944, 5361215, 5550753, 5559720, 5,883,459, 6253227, 6282370, 6590188, 6976052, 6965815, 7030343, 7,417,834 b2, Canadian Patent: 2342614, Australian patent: 2373248 other patents both foreign and domestic applied for and pending.

A2

Α3

Α4

A1



Template 56377 10-05-12

G3381_97_A 03-27-23